



FIG-1





F1G.-3





FIG. -4

FIG-5A







FIG-5C






FIG-6




FIG-7

94

FIG-7A € 00 ر مع 96B 96C 91E 91D 98B 96A 97B 96 ر 97A 98A 91C C3 | C1 91B **S**3 S2




FIG-8




FIG-9




FIG-10




FIG-11





FIG-11A






FIG-12




FIG-13




FIG-13A





FIG - 14



HIDE IN DRAWER (SEE FIG. 11), OR SET ON ANY SURFACE NEAR TELEVISION

ARCADE STYLE CONTROLS
ANYWHERE

FIG -15